

Transport of dynamically fragmented polystyrene (PS) microplastics through saturated porous media

Presentation by

Ahmad Ameen^{1,3}, Julia Derx^{1,3}, Stefan Jakwerth^{2,3}, Gerhard Lindner^{1,2,3},
Alexander K. T. Kirschner^{2,3}, Alfred Paul Blaschke^{1,3}, Margaret E. Stevenson^{1,3}

1. INSTITUTE OF HYDRAULIC ENGINEERING AND WATER RESOURCES MANAGEMENT, TU WIEN, AUSTRIA.
2. INSTITUTE FOR HYGIENE AND APPLIED IMMUNOLOGY, MEDICAL UNIVERSITY OF VIENNA, AUSTRIA.
3. INTERUNIVERSITY COOPERATION CENTRE (ICC) WATER AND HEALTH, VIENNA, AUSTRIA.






What are microplastics (MPs)?

- As per European Commission, fragmented plastics in a size range of **0.1 μm to 5 mm** (*Mendoza and Balcer 2019*)

Potential threats to groundwater system?

- For groundwater micron-sized MPs are more relevant (*Ameen et., al. 2020*)
- Less than **20% of global studies** considered MPs size below **20 μm** , which are more relevant for groundwater studies.
- Mobile pore scale MPs in the hyporheic zone can be transferred into the aquifer.
- MPs in shallow groundwater can be a potential threat for drinking water (i.e. riverbank filtration) (*Frei et., al. 2019*)

Sources of MPs pollution







Motivation


Understand the transport behaviour of MPs in different porous media;

1. Effect of MPs **shape**
2. Effect of **porous media**
3. A **new method of analysing** MPs


Methodology




**Dynamic
fragmentation of
microspheres
(10 & 20 μm)**



**Column
experiment**



**Identification by
Solid-phase Cytometry**

Stevenson, et al., 2014



Process of dynamic fragmentation

Preparation

Microspheres
(10 and 20 μm)



Adding
glass beads






Fragmentation by
Homogenizer




Rev: 10 m/s
Time: 20 s

Fragmented MP



Fragmented MP size distribution





Parameters - column experiments

Column size:


$d = 7 \text{ cm}$, $L = 30 \text{ cm}$



Medium Gravel
(8 mm)



Fine Gravel
(4 mm)



Coarse Quartz
(0.6 to 1.3 mm)



Medium Quartz
(0.4 to 0.8 mm)




Parameters

Porosity	0.38	0.36	0.41	0.43
Darcy velocity (m/d)	1.5	1.5	1.5	1.5
Flow rate (ml/min)	4	4	4	4
Avg. size FMP (μm)	1.55	1.70	1.44	1.36
FMPs injected (par/ml)	1.65×10^4	5.75×10^4	1.45×10^4	1.72×10^4




Results


Medium Gravel (8 mm)




Fine Gravel (4 mm)



Coarse Quartz (0.6-1.3 mm)



Medium Quartz (0.4-0.8 mm)



Key findings

- Higher deposition of fragmented MPs due to
 - uneven shape and surface irregularity (e.g. aspect ratio)
 - Surface heterogeneity of the porous media
- Re-orientation of fragmented MPs near pore-spaces.
- Tumbling (rotational) movement of the fragmented MPs.
- Hydrus 1D - high values of attachment coefficient of fragmented MPs.



Conclusion

- Surface roughness and irregularity of fragmented MPs was more important than straining.
- The impact of grain and pore size on fragmented MPs was evident.
- Non-uniform MPs should be used for realistic groundwater investigations.
- Highly dynamic riverbank filtration systems (often used as a safe drinking water resource) should be investigated for irregular-shaped MPs as tracers.



Thank you for your attention

Questions